

ProSaber Mounting EN

You got your hand on one of a ProSabers. With it, you will be able to play in Darth Maul mode in Beat Saber and similar games, or use it a paddle for kayaking.

🕒 Mounting your ProSaber should take 10 minutes.

Make sure you work in a clear area and be very careful. Some parts can easily be lost.

Parts list

ProSaber bag



x2

Nut



x2

20mm screw



x1

Hex Key 0,4cm

Rest of the box



x2

Left & Right Fastened Cup



x1

Tube 300mm chrome or carbon



x2

Connection with internal notches

Mounting



First, make sure you have everything you need to mount your ProSaber.



The screw needs to go on the cup and the nut on the internal notched connection.



If you are having trouble inserting the screw on the cup, you can use the Hex key to screw it in.



The nut needs to go on the internal notched connection.



Before tightening the screw, make sure it is aligned with the tube (example for Quest 2). It is preferable to put the controller in the cup to better realize this.



Tighten the screw using the provided Hex key.



Make sure to tighten it strongly, so the cup won't move at all.



Do this with the other cup. You now have a fully functioning ProSaber!



Finally, insert the controllers in the cups, make sure to push them enough so they stay in. Enjoy this Darth Maul mod Saber.

Controllers Security



Pass the controller's wrist strap into the cup's hole.



The, around the controller.



And finally, under the cup.



Use the slider to tighten it on the ProSaber.



Push the controller into the cup. The more you push, the more it stays in the cup. Be careful not to push too much, though. It might damage the controller and/or the cups.

Revision #11

Created 24 April 2025 09:30:17 by jon

Updated 30 October 2025 15:15:52 by Sephooth