


Basic troubleshooting & tips

1. The ProSaber holds the controller in by maintaining friction in the cup, and the wrist strap is secured as a final failsafe should it come loose during use. It is important to maintain that friction. You can do so by wiping the controllers down so they are clean before use, and during use regularly pushing the controllers back in before they come loose.
2. If your headset/controllers use inside out tracking, you will need to keep the ProSaber in front of you at all times for optimal tracking to prevent tracking loss. This may take some practice but you will get a feel for where you can have it and where you can't. **Lastly, if you are using a Meta headset then disable hand tracking during use.**
3. If you have difficulty securing your controllers and keeping them in the cup, even with wiping them down etc. try this method from community member Likon:



Revision #1

Created 25 March 2025 03:49:58 by jon

Updated 25 March 2025 03:51:19 by jon