

Getting Started

Getting Started (haptic device):

1. After unboxing, the first thing you will need to do is charge your device. It arrives on low charge and takes about 7-8 hours to charge to full. You will know it is charging by the blinking yellow/orange LED when plugged in. To charge it, use the provided cable on a PC USB port, or 500mA USB charger. Again, if you do not see a blinking yellow/orange LED when plugged in, it is not charging and you will need to try a different power source. Quest headset power adapters will not charge your haptic device, for example.

2. Once fully charged (LED behavior varies, it will either show a white LED, or when unplugging from power and turning on the device will show a white LED) you may now pair to your respective VR setup. For PC you are pairing your device to PC, and for Standalone you are pairing your device directly to your headset. If you are using a Standalone HMD on PC, you will pair to PC.

Getting Started (gun stock; no ProStraps):

1. After setting your ForceTube to charge, the next thing you need to do is get the mag cups (AKA controller mounts). They will be in their own bubble wrap bag, or already on the MagTube. If they are already on the ForceTube gun stock, you can grab a cup firmly, and remove by using a doorknob twist motion.

2. On each cup will be writing to indicate if it is for the left or right controller. Underneath, where you see the magnet, you might also see some more writing indicating which brand the cups are for (i.e. Quest 2). Inside of the cups should be an inner layer. This allows for maximum friction to keep the controller in place. Please note: if you ordered ProStraps, they might already be pre-installed on the cups.

3. Before putting your controllers into the cups, it is suggested to wipe down the part of the controllers that will go inside. This is to ensure optimal friction so they do not slide out easily. Next, observe the small hole in the cup. This is intended for feeding the wrist strap through, and should be facing you, or away from the trigger button on the controller. The magnet on the bottom of the left cup should be angled towards the right, and the magnet on the bottom of the right cup angled towards the left.

4. To install, simply start with the wrist strap and feed it through the small hole. Then push the controller into the cup until it cannot go any further. Use of excessive force is not required as it should easily go in until it hits friction, and then with a little bit of force you should be able to continue pushing in until it won't go any further. That is the point at which you should stop and it is

considered installed in the cup. Please note: if you are using Index we have videos in Website tutorials under Cup.

Getting Started (gun stock; with ProStraps):

Follow steps 1-3 from above. Before putting controllers into the cups you will need to install the ProStraps as shown in our tutorials. Depending on your controller brand, and the state in which they were received (pre-installed vs separately) what you do may vary. But essentially, you need the bottom to be on the cup, and the top to either be connected to an insert you put inside your controller's battery cover, or inside the cup itself. Make sure to follow the tutorial for your controller brand.

Once the ProStraps are correctly installed, you follow step 4 above.

Revision #1

Created 25 March 2025 04:19:27 by jon

Updated 28 March 2025 15:53:18 by jon